

I'm not a bot































If your tower fan has stopped working, check for damage, clean blades, and ensure a secure power connection. Tower fans may stop working due to damaged blades or motor issues.Regular cleaning and maintenance can help prolong the life of your tower fan.If your tower fan suddenly stops working, it could be due to various issues such as a lack of power, damaged fan blades, or a malfunctioning motor. Inspect and clean the blades and motor to ensure they're free from damage and debris.Check the power connection and try plugging the fan into a different outlet to troubleshoot the issue.Lack Of PowerIf your tower fan seems unresponsive, check if it's properly plugged in. Ensure the connection is secure in the socket. If the issue persists, try a different outlet.Fan Blades And Motor InspectionInspect the fan blades and motor for wear or damage. Clean away dust and debris from the blades and tighten any loose screws. Consider replacing the motor if it's not functioning." Note: This HTML content is optimized for readability, providing insights about common issues with tower fans, specifically focusing on lack of power and the importance of inspecting fan blades and motor.Credit: www.amazon.comHaving trouble with your tower fan not working? Check for any damage on the fan blades and motor. Clean off dust and tighten loose screws. If the motor is faulty, consider replacing it for a quick solution.Checking Power SupplyEnsure the tower fan is properly plugged in and check the connection to the power source.Make sure the power outlet is functioning correctly.Test the fan on a different outlet to rule out electrical issues.Cleaning And MaintenanceRegular cleaning can help resolve some common tower fan issues.Clean the fan blades: Remove dust and debris that may hinder the fan's operation.Tighten screws: Check for loose screws that may affect the fan's stability.Maintain motor: Keep the motor clean and ensure it is functioning smoothly.Motor ReplacementIf the fan still does not work, consider replacing the motor.Consult the manufacturer for replacement parts.Follow instructions carefully when replacing the motor to avoid further damage.Regular maintenance is essential to keep your tower fan in good working condition. By following a few preventive maintenance tips, you can extend the lifespan of your tower fan and ensure it operates efficiently. Here are some essential maintenance steps you should take to keep your tower fan in top shape.Regular CleaningMaintaining clean fan blades and a dust-free motor is crucial for the proper functioning of a tower fan. Over time, dust and debris can accumulate on the blades and hinder airflow, leading to decreased performance. Regularly clean the fan blades and motor using a soft brush or cloth to remove any dust and dirt. This will help prevent blockages and ensure optimal airflow.Proper LubricationApplying lubrication to the fan's moving parts helps reduce friction and wear, prolonging the fan's lifespan. You can lubricate the fan's bearings and shafts with a suitable lubricant to keep them running smoothly. Proper lubrication also helps to minimize noise and vibration, enhancing the overall performance of the tower fan.Avoiding OverloadIt's important to avoid overloading the tower fan, as this can lead to overheating and premature wear of the motor. Be mindful of the fan's power rating and avoid using it with other heavy electrical appliances on the same circuit. Overloading the fan can cause it to stop working or lead to potential damage to its internal components.Credit: www.amazon.comIn addition to tower fans, there are many other types of fans that can encounter issues and stop working. Understanding how to troubleshoot and fix these problems can save you the hassle and expense of buying a new fan. In this section, we'll explore common troubleshooting techniques for standing fans and ceiling fans.If your standing fan has stopped working, there are a few things you can check before assuming it's broken beyond repair. Here are some steps you can take to try and fix the issue:Ensure that the fan is properly plugged in and that the connection to the wall socket is secure.If the fan still doesn't work, check the power supply by plugging it into another outlet. Sometimes, a faulty outlet can be the cause of the issue.Inspect the fan blades and motor for any signs of damage or wear and tear. Clean the blades to remove any dust or debris that may be causing them to jam.Lubricate the middle fan shaft and bearings to ensure smooth operation. You can use a lightweight oil or silicone lubricant for this purpose.Check if the heat sink holes and motor housing are clogged. If they are, clean them using a soft brush or compressed air.If none of these steps resolve the issue, it may be a more serious problem that requires professional repair or replacement.A ceiling fan that has stopped working can be frustrating, especially during hot summer days. Here are some troubleshooting tips to help you identify and fix the problem:Start by checking the power supply. Make sure the fan is properly connected to the electric circuit and that the circuit breaker or fuse hasn't tripped.If the power supply is fine, inspect the fan blades for any obstructions. Remove any dust, dirt, or debris that may be preventing the blades from spinning freely.Check the pull chain switch or remote control to ensure it is functioning properly. Sometimes, a faulty switch or remote can cause the fan to stop working.If the fan still doesn't work, try reversing the direction of the blades. This can sometimes help to reset the internal mechanism of the fan.If none of these troubleshooting steps solve the issue, it may be a more complex problem that requires professional assistance. When your tower fan suddenly stops working, it can be frustrating and inconvenient. However, you don't have to face this problem alone. There are various resources and community support available to help you troubleshoot and repair your fan.Online Forums And CommunitiesOnline forums and communities provide a platform for individuals facing similar issues to come together and seek solutions. These platforms are a great source of information and support, allowing you to connect with experienced individuals who have encountered and resolved similar problems.If you're looking for answers to why your tower fan stopped working, joining relevant forums and communities can be immensely helpful. You can post your specific issue and receive advice from knowledgeable members who can guide you through the troubleshooting process.Moreover, forums and communities often contain threads where users have discussed common tower fan problems and shared their experiences with repairing them. By browsing through these threads, you may find valuable tips, suggestions, and step-by-step instructions to fix your fan.Video Tutorials For Repairing FansVideo tutorials are an incredibly helpful resource when it comes to repairing your tower fan. These tutorials provide visual demonstrations, making it easier to understand the repair process and follow along.On platforms like YouTube, you can find a wide variety of video tutorials specifically dedicated to fixing tower fans. These videos are created by experts who share their knowledge and expertise, offering detailed explanations of each step involved in the repair process.From disassembling the fan and cleaning the components to identifying faulty parts and replacing them, these video tutorials cover various repair scenarios. Following these tutorials can save you time and money by enabling you to fix your tower fan without the need for professional help.By utilizing these resources and community support options, you can take control of the situation and potentially save yourself from the hassle and expense of buying a new fan. Remember to always exercise caution when attempting repairs, and if you're unsure or uncomfortable, consult a professional technician to avoid any further damage.Credit: www.nytimes.comA fan may stop working due to damaged blades, motor issues, or debris accumulation. Check for damage, clean blades, tighten screws, and replace the motor if necessary. Make sure the fan is plugged in properly or try a different outlet for power.If your tower fan is not coming on, check the power source. Ensure it's plugged in properly and try a different outlet. Clean and tighten the fan components for any damage. If the motor is not functioning, consider replacing it.Regular maintenance can also prevent such issues.Tower fans are designed to last for a long time, but they are not meant to last indefinitely. If your tower fan is over five years old, it's a good idea to inspect it for any signs of damage or wear and tear.Regular cleaning and maintenance can also help extend its lifespan.To fix a standing fan that stopped working, make sure it is plugged in and check the connection to the wall socket. If the fan blades don't spin or make noise, lubricate the middle fan shaft and bearings, and clean the heat sink holes and motor housing.A: Inspect the fan blades and motor for any signs of damage or wear and tear. Clean the blades to ensure they are not clogged with dust or debris, and tighten any loose screws or bolts. If the motor is not working, it may need to be replaced.If your tower fan has suddenly stopped working, don't fret. Your fan may just need a simple fix. Check for dust and debris that might be affecting its operation, and make sure it's properly plugged in. With a little maintenance, your fan could be up and running again in no time. Reddit and its partners use cookies and similar technologies to provide you with a better experience. By accepting all cookies, you agree to our use of cookies to deliver and maintain our services and site, improve the quality of Reddit, personalize Reddit content and advertising, and measure the effectiveness of advertising. By rejecting non-essential cookies, Reddit may still use certain cookies to ensure the proper functionality of our platform. For more information, please see our Cookie Notice and our Privacy Policy. Tower fans are awesome devices for the upcoming hot summer days but they're not infallible. Like any other piece of electronics, they too can malfunction and exhibit certain problems. Below we'll list the most common tower fan issues you may experience and what they usually mean. Tower fan overheating Newer models won't do this often but it does happen. It was especially common for older tower fans. Overheating happens because the vertical design of the fan can sometimes lead to trapped air between the fan's turbines. That's because the space inside the fan is rather compact. If air gets trapped inside your fan, overheating is quite possible. Another cause for this might be that the air's exit is blocked by a piece of furniture or by dust and debris inside the fan. Tower fan making rattling noises Rattling in tower fans is usually caused by one of two possible causes. The first is loose fan blades. This happens over time, typically due to the dust and debris that go through the fan. That's why it's important to periodically open your fan and do a routine checkup on its inner workings. The other possible cause is a loosened front grill. This can happen if you haven't screwed it properly or if the screws have slowly come loose from the fan's vibrations. Tower fan not blowing air If your tower fan seems to be working but isn't blowing out any air, that's most probably because it's clogged with dust, debris, hair, and other materials. Even if the blades are moving, if the grills are blocked, the tower fan won't pass any air. If you don't fix the problem quickly, it's very likely that the fan will soon overheat and/or stop working altogether. Tower fan stopped working There are many possible reasons why a tower fan has stopped working. Some of the above problems can also lead to that - overheating, clogged and obstructed fan turbines, etc. Another cause might be a loose power plug. This can sound funny but it's not that uncommon for the fan's vibration to gradually loosen the plug until it disconnects from the power outlet. To fix that you can get a new outlet that's tighter and won't lose the connection with the fan's plug. What to do in these situations? Thankfully, tower fans are pretty simple devices. Because of that, fixing them is relatively simple as well. All of these problems can be taken care of with some proper tower fan maintenance - simply open the fan, clean it, make sure everything is tightly connected where and how it should be and put the fan back together. Such routine maintenance won't only fix these common problems. It will also prevent them from happening in the future. Holmes HT38R, HT38RB2, HTF3610AR - Remote Control Tower Fan Manual FEATURES - OPERATIONS ASSEMBLY INSTRUCTIONS Assembly Time: 10-15 minutes. Tools Required: Phillips head screw driver. NOTE: MAKE SURE YOU REMOVE ALL CONTENTS FROM THE PACKAGE. PLEASE CHECK PACKAGING MATERIALS FOR PARTS THAT COULD BE REQUIRED TO OPERATE YOUR FAN. LOCATE THE BELOW PARTS FROM THE BOX TO PREPARE FOR ASSEMBLY: Fan housing 2 pedestal halves 2 base halves 8 M4x8mm screws (4 pcs for pedestal assembly and 4 pcs for base assembly) Cord clip with 2 M4x12mm screws (affixed underneath the base inside the package box) Remote Control (placed in a plastic bag inside the package box) Follow the steps below in order to assemble the fan pedestal and base before operating your fan: To assemble the pedestal, simply snap the 2 pedestal halves together. Pull the power cord through the assembled pedestal, making sure the wider end of the pedestal is facing towards the fan housing. Align marking "A", located at the bottom of the fan housing, with marking "A" on the top end of the pedestal. Insert the alignment post from the pedestal into the alignment hole on fan housing for proper alignment. Use 4 screws (M4x8mm) provided to attach the assembled pedestal to the bottom of the fan housing. Secure the screws with a screwdriver. Snap the 2 base halves together by sliding the posts of one base half into the slots of the second base half. Pull the power cord through the center hole of the assembled base. Align marking "B", located at the center hole of the assembled base, with marking "B" at the bottom end of the pedestal. Insert the alignment post from the pedestal into the alignment hole on base for proper alignment. Use 4 screws (M4x8mm) provided to attach the assembled base to the pedestal. Secure the screws with a screwdriver. Wind the power cord underneath the base. Loosen the cord clip and place cord inside the clip. Secure the cord clip onto the base bottom with the 2 screws (M4x12mm) provided. Turn fan right side up and place on a dry and level surface before operating. OPERATING INSTRUCTIONS Power/Speed Settings / Press / = On, I, II, III, Off Timer Control Press = Turns Off in 1, 2, 4, 8 hours Oscillation Control Press = Oscillation On, Off Natural Breeze, Sleep Breeze Modes / Press / = Natural Breeze, Sleep Breeze Natural Breeze Mode will cycle through the fan speed settings randomly. Sleep Breeze Mode will cycle through the fan speed settings in order. FCC STATEMENT Potential for Radio/Television Interference This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: This device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation. This product has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. REMOTE CONTROL This fan includes a remote control requiring two (2) AAA batteries, 1.5V (not included). Battery Replacement Remove battery cover from remote control. Remove old batteries from the remote control. Insert two new batteries, pressing them firmly into their slot. Replace the battery cover. NOTES: Replace all batteries of a set at the same time. Being careful not to bend or damage the contact spring, clean the battery contacts and devices' contacts prior to installing the batteries. Remove the batteries from the equipment when it is not being used for an extended period of time. Remove the used batteries promptly. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries. Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area. CLEANING/MAINTENANCE INSTRUCTIONS Follow these instructions to correctly and safely care for your Tower Fan. Please remember: REPLACEABLE FUSE If your (5 Amp, 125 Volt) replaceable fuse blows, please visit our website at www.holmesproducts.com for information on how to order a new fuse. Follow the below instructions to replace the fuse on the plug. User Servicing Instructions Unplug your fan. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord. Open fuse cover, located on the top of the plug, by using your thumb or a flathead screwdriver to slide the cover down towards the prongs. Note: Ensure that fuse cover is completely open before attempting to remove fuse. Remove fuse carefully by using a small screwdriver to pry the fuse out of the compartment by the metal ends of the fuse. Place plug on a solid, flat surface. Insert new 5 Amp, 125 Volt fuse into fuse compartment and use a small screwdriver to secure the metal ends of the fuse into the compartment. Risk of fire. Replace fuse only with 5 Amp, 125 Volt fuse. Slide fuse cover closed completely. If fuse cover is difficult to close, make sure fuse is secured in place completely by pressing down on metal ends of the fuse. Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if the attachment plug is damaged. Fan CLEANING Always unplug the fan before cleaning. Clean fan housing 2 pedestal halves 2 base halves 8 M4x8mm screws (4 pcs for pedestal assembly and 4 pcs for base assembly) Cord clip with 2 M4x12mm screws (affixed underneath the base inside the package box) Remote Control (placed in a plastic bag inside the package box) Follow the steps below in order to assemble the fan pedestal and base before operating your fan: To assemble the pedestal, simply snap the 2 pedestal halves together. Pull the power cord through the assembled pedestal, making sure the wider end of the pedestal is facing towards the fan housing. Align marking "A", located at the bottom of the fan housing, with marking "A" on the top end of the pedestal. Insert the alignment post from the pedestal into the alignment hole on fan housing for proper alignment. Use 4 screws (M4x8mm) provided to attach the assembled base to the pedestal. Secure the screws with a screwdriver. Wind the power cord underneath the base. Loosen the cord clip and place cord inside the clip. Secure the cord clip onto the base bottom with the 2 screws (M4x12mm) provided. Turn fan right side up and place on a dry and level surface before operating. OPERATING INSTRUCTIONS Power/Speed Settings / Press / = On, I, II, III, Off Timer Control Press = Turns Off in 1, 2, 4, 8 hours Oscillation Control Press = Oscillation On, Off Natural Breeze, Sleep Breeze Modes / Press / = Natural Breeze, Sleep Breeze Natural Breeze Mode will cycle through the fan speed settings randomly. Sleep Breeze Mode will cycle through the fan speed settings in order. FCC STATEMENT Potential for Radio/Television Interference This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: This device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation. This product has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. REMOTE CONTROL This fan includes a remote control requiring two (2) AAA batteries, 1.5V (not included). Battery Replacement Remove battery cover from remote control. Remove old batteries from the remote control. Insert two new batteries, pressing them firmly into their slot. Replace the battery cover. NOTES: Replace all batteries of a set at the same time. Being careful not to bend or damage the contact spring, clean the battery contacts and devices' contacts prior to installing the batteries. Remove the batteries from the equipment when it is not being used for an extended period of time. Remove the used batteries promptly. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries. Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area. CLEANING/MAINTENANCE INSTRUCTIONS Follow these instructions to correctly and safely care for your Tower Fan. Please remember: REPLACEABLE FUSE If your (5 Amp, 125 Volt) replaceable fuse blows, please visit our website at www.holmesproducts.com for information on how to order a new fuse. Follow the below instructions to replace the fuse on the plug. User Servicing Instructions Unplug your fan. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord. Open fuse cover, located on the top of the plug, by using your thumb or a flathead screwdriver to slide the cover down towards the prongs. Note: Ensure that fuse cover is completely open before attempting to remove fuse. Remove fuse carefully by using a small screwdriver to pry the fuse out of the compartment by the metal ends of the fuse. Place plug on a solid, flat surface. Insert new 5 Amp, 125 Volt fuse into fuse compartment and use a small screwdriver to secure the metal ends of the fuse into the compartment. Risk of fire. Replace fuse only with 5 Amp, 125 Volt fuse. Slide fuse cover closed completely. If fuse cover is difficult to close, make sure fuse is secured in place completely by pressing down on metal ends of the fuse. Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if the attachment plug is damaged. Fan CLEANING Always unplug the fan before cleaning. Clean fan housing 2 pedestal halves 2 base halves 8 M4x8mm screws (4 pcs for pedestal assembly and 4 pcs for base assembly) Cord clip with 2 M4x12mm screws (affixed underneath the base inside the package box) Remote Control (placed in a plastic bag inside the package box) Follow the steps below in order to assemble the fan pedestal and base before operating your fan: To assemble the pedestal, simply snap the 2 pedestal halves together. Pull the power cord through the assembled pedestal, making sure the wider end of the pedestal is facing towards the fan housing. Align marking "A", located at the bottom of the fan housing, with marking "A" on the top end of the pedestal. Insert the alignment post from the pedestal into the alignment hole on fan housing for proper alignment. Use 4 screws (M4x8mm) provided to attach the assembled base to the pedestal. Secure the screws with a screwdriver. Wind the power cord underneath the base. Loosen the cord clip and place cord inside the clip. Secure the cord clip onto the base bottom with the 2 screws (M4x12mm) provided. Turn fan right side up and place on a dry and level surface before operating. OPERATING INSTRUCTIONS Power/Speed Settings / Press / = On, I, II, III, Off Timer Control Press = Turns Off in 1, 2, 4, 8 hours Oscillation Control Press = Oscillation On, Off Natural Breeze, Sleep Breeze Modes / Press / = Natural Breeze, Sleep Breeze Natural Breeze Mode will cycle through the fan speed settings randomly. Sleep Breeze Mode will cycle through the fan speed settings in order. FCC STATEMENT Potential for Radio/Television Interference This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: This device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation. This product has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. REMOTE CONTROL This fan includes a remote control requiring two (2) AAA batteries, 1.5V (not included). Battery Replacement Remove battery cover from remote control. Remove old batteries from the remote control. Insert two new batteries, pressing them firmly into their slot. Replace the battery cover. NOTES: Replace all batteries of a set at the same time. Being careful not to bend or damage the contact spring, clean the battery contacts and devices' contacts prior to installing the batteries. Remove the batteries from the equipment when it is not being used for an extended period of time. Remove the used batteries promptly. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries. Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area. CLEANING/MAINTENANCE INSTRUCTIONS Follow these instructions to correctly and safely care for your Tower Fan. Please remember: REPLACEABLE FUSE If your (5 Amp, 125 Volt) replaceable fuse blows, please visit our website at www.holmesproducts.com for information on how to order a new fuse. Follow the below instructions to replace the fuse on the plug. User Servicing Instructions Unplug your fan. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord. Open fuse cover, located on the top of the plug, by using your thumb or a flathead screwdriver to slide the cover down towards the prongs. Note: Ensure that fuse cover is completely open before attempting to remove fuse. Remove fuse carefully by using a small screwdriver to pry the fuse out of the compartment by the metal ends of the fuse. Place plug on a solid, flat surface. Insert new 5 Amp, 125 Volt fuse into fuse compartment and use a small screwdriver to secure the metal ends of the fuse into the compartment. Risk of fire. Replace fuse only with 5 Amp, 125 Volt fuse. Slide fuse cover closed completely. If fuse cover is difficult to close, make sure fuse is secured in place completely by pressing down on metal ends of the fuse. Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if the attachment plug is damaged. Fan CLEANING Always unplug the fan before cleaning. Clean fan housing 2 pedestal halves 2 base halves 8 M4x8mm screws (4 pcs for pedestal assembly and 4 pcs for base assembly) Cord clip with 2 M4x12mm screws (affixed underneath the base inside the package box) Remote Control (placed in a plastic bag inside the package box) Follow the steps below in order to assemble the fan pedestal and base before operating your fan: To assemble the pedestal, simply snap the 2 pedestal halves together. Pull the power cord through the assembled pedestal, making sure the wider end of the pedestal is facing towards the fan housing. Align marking "A", located at the bottom of the fan housing, with marking "A" on the top end of the pedestal. Insert the alignment post from the pedestal into the alignment hole on fan housing for proper alignment. Use 4 screws (M4x8mm) provided to attach the assembled base to the pedestal. Secure the screws with a screwdriver. Wind the power cord underneath the base. Loosen the cord clip and place cord inside the clip. Secure the cord clip onto the base bottom with the 2 screws (M4x12mm) provided. Turn fan right side up and place on a dry and level surface before operating. OPERATING INSTRUCTIONS Power/Speed Settings / Press / = On, I, II, III, Off Timer Control Press = Turns Off in 1, 2, 4, 8 hours Oscillation Control Press = Oscillation On, Off Natural Breeze, Sleep Breeze Modes / Press / = Natural Breeze, Sleep Breeze Natural Breeze Mode will cycle through the fan speed settings randomly. Sleep Breeze Mode will cycle through the fan speed settings in order. FCC STATEMENT Potential for Radio/Television Interference This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: This device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation. This product has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. REMOTE CONTROL This fan includes a remote control requiring two (2) AAA batteries, 1.5V (not included). Battery Replacement Remove battery cover from remote control. Remove old batteries from the remote control. Insert two new batteries, pressing them firmly into their slot. Replace the battery cover. NOTES: Replace all batteries of a set at the same time. Being careful not to bend or damage the contact spring, clean the battery contacts and devices' contacts prior to installing the batteries. Remove the batteries from the equipment when it is not being used for an extended period of time. Remove the used batteries promptly. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries. Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area. CLEANING/MAINTENANCE INSTRUCTIONS Follow these instructions to correctly and safely care for your Tower Fan. Please remember: REPLACEABLE FUSE If your (5 Amp, 125 Volt) replaceable fuse blows, please visit our website at www.holmesproducts.com for information on how to order a new fuse. Follow the below instructions to replace the fuse on the plug. User Servicing Instructions Unplug your fan. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord. Open fuse cover, located on the top of the plug, by using your thumb or a flathead screwdriver to slide the cover down towards the prongs. Note: Ensure that fuse cover is completely open before attempting to remove fuse. Remove fuse carefully by using a small screwdriver to pry the fuse out of the compartment by the metal ends of the fuse. Place plug on a solid, flat surface. Insert new 5 Amp, 125 Volt fuse into fuse compartment and use a small screwdriver to secure the metal ends of the fuse into the compartment. Risk of fire. Replace fuse only with 5 Amp, 125 Volt fuse. Slide fuse cover closed completely. If fuse cover is difficult to close, make sure fuse is secured in place completely by pressing down on metal ends of the fuse. Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if the attachment plug is damaged. Fan CLEANING Always unplug the fan before cleaning. Clean fan housing 2 pedestal halves 2 base halves 8 M4x8mm screws (4 pcs for pedestal assembly and 4 pcs for base assembly) Cord clip with 2 M4x12mm screws (affixed underneath the base inside the package box) Remote Control (placed in a plastic bag inside the package box) Follow the steps below in order to assemble the fan pedestal and base before operating your fan: To assemble the pedestal, simply snap the 2 pedestal halves together. Pull the power cord through the assembled pedestal, making sure the wider end of the pedestal is facing towards the fan housing. Align marking "A", located at the bottom of the fan housing, with marking "A" on the top end of the pedestal. Insert the alignment post from the pedestal into the alignment hole on fan housing for proper alignment. Use 4 screws (M4x8mm) provided to attach the assembled base to the pedestal. Secure the screws with a screwdriver. Wind the power cord underneath the base. Loosen the cord clip and place cord inside the clip. Secure the cord clip onto the base bottom with the 2 screws (M4x12mm) provided. Turn fan right side up and place on a dry and level surface before operating. OPERATING INSTRUCTIONS Power/Speed Settings / Press / = On, I, II, III, Off Timer Control Press = Turns Off in 1, 2, 4, 8 hours Oscillation Control Press = Oscillation On, Off Natural Breeze, Sleep Breeze Modes / Press / = Natural Breeze, Sleep Breeze Natural Breeze Mode will cycle through the fan speed settings randomly. Sleep Breeze Mode will cycle through the fan speed settings in order. FCC STATEMENT Potential for Radio/Television Interference This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: This device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation. This product has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. REMOTE CONTROL This fan includes a remote control requiring two (2) AAA batteries, 1.5V (not included). Battery Replacement Remove battery cover from remote control. Remove old batteries from the remote control. Insert two new batteries, pressing them firmly into their slot. Replace the battery cover. NOTES: Replace all batteries of a set at the same time. Being careful not to bend or damage the contact spring, clean the battery contacts and devices' contacts prior to installing the batteries. Remove the batteries from the equipment when it is not being used for an extended period of time. Remove the used batteries promptly. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries. Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area. CLEANING/MAINTENANCE INSTRUCTIONS Follow these instructions to correctly and safely care for your Tower Fan. Please remember: REPLACEABLE FUSE If your (5 Amp, 125 Volt) replaceable fuse blows, please visit our website at www.holmesproducts.com for information on how to order a new fuse. Follow the below instructions to replace the fuse on the plug. User Servicing Instructions Unplug your fan. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord. Open fuse cover, located on the top of the plug, by using your thumb or a flathead screwdriver to slide the cover down towards the prongs. Note: Ensure that fuse cover is completely open before attempting to remove fuse. Remove fuse carefully by using a small screwdriver to pry the fuse out of the compartment by the metal ends of the fuse. Place plug on a solid, flat surface. Insert new 5 Amp, 125 Volt fuse into fuse compartment and use a small screwdriver to secure the metal ends of the fuse into the compartment. Risk of fire. Replace fuse only with 5 Amp, 125 Volt fuse. Slide fuse cover closed completely. If fuse cover is difficult to close, make sure fuse is secured in place completely by pressing down on metal ends of the fuse. Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if the attachment plug is damaged. Fan CLEANING Always unplug the fan before cleaning. Clean fan housing 2 pedestal halves 2 base halves 8 M4x8mm screws (4 pcs for pedestal assembly and 4 pcs for base assembly) Cord clip with 2 M4x12mm screws (affixed underneath the base inside the package box) Remote Control (placed in a plastic bag inside the package box) Follow the steps below in order to assemble the fan pedestal and base before operating your fan: To assemble the pedestal, simply snap the 2 pedestal halves together. Pull the power cord through the assembled pedestal, making sure the wider end of the pedestal is facing towards the fan housing. Align marking "A", located at the bottom of the fan housing, with marking "A" on the top end of the pedestal. Insert the alignment post from the pedestal into the alignment hole on fan housing for proper alignment. Use 4 screws (M4x8mm) provided to attach the assembled base to the pedestal. Secure the screws with a screwdriver. Wind the power cord underneath the base. Loosen the cord clip and place cord inside the clip. Secure the cord clip onto the base bottom with the 2 screws (M4x12mm) provided. Turn fan right side up and place on a dry and level surface before operating. OPERATING INSTRUCTIONS Power/Speed Settings / Press / = On, I, II, III, Off Timer Control Press = Turns Off in 1, 2, 4, 8 hours Oscillation Control Press = Oscillation On, Off Natural Breeze, Sleep Breeze Modes / Press / = Natural Breeze, Sleep Breeze Natural Breeze Mode will cycle through the fan speed settings randomly. Sleep Breeze Mode will cycle through the fan speed settings in order. FCC STATEMENT Potential for Radio/Television Interference This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: This device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation. This product has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. REMOTE CONTROL This fan includes a remote control requiring two (2) AAA batteries, 1.5V (not included). Battery Replacement Remove battery cover from remote control. Remove old batteries from the remote control. Insert two new batteries, pressing them firmly into their slot. Replace the battery cover. NOTES: Replace all batteries of a set at the same time. Being careful not to bend or damage the contact spring, clean the battery contacts and devices' contacts prior to installing the batteries. Remove the batteries from the equipment when it is not being used for an extended period of time. Remove the used batteries promptly. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries. Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area. CLEANING/MAINTENANCE INSTRUCTIONS Follow these instructions to correctly and safely care for your Tower Fan. Please remember: REPLACEABLE FUSE If your (5 Amp, 125 Volt) replaceable fuse blows, please visit our website at www.holmesproducts.com for information on how to order a new fuse. Follow the below instructions to replace the fuse on the plug. User Servicing Instructions Unplug your fan. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord. Open fuse cover, located on the top of the plug, by using your thumb or a flathead screwdriver to slide the cover down towards the prongs. Note: Ensure that fuse cover is completely open before attempting to remove fuse. Remove fuse carefully by using a small screwdriver to pry the fuse out of the compartment by the metal ends of the fuse. Place plug on a solid, flat surface. Insert new 5 Amp, 125 Volt fuse into fuse compartment and use a small screwdriver to secure the metal ends of the fuse into the compartment. Risk of fire. Replace fuse only with 5 Amp, 125 Volt fuse. Slide fuse cover closed completely. If fuse cover is difficult to close, make sure fuse is secured in place completely by pressing down on metal ends of the fuse. Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if the attachment plug is damaged. Fan CLEANING Always unplug the fan before cleaning. Clean fan housing 2 pedestal halves 2 base halves 8 M4x8mm screws (4 pcs for pedestal assembly and 4 pcs for base assembly) Cord clip with 2 M4x12mm screws (affixed underneath the base inside the package box) Remote Control (placed in a plastic bag inside the package box) Follow the steps below in order to assemble the fan pedestal and base before operating your fan: To assemble the pedestal, simply snap the 2 pedestal halves together. Pull the power cord through the assembled pedestal, making sure the wider end of the pedestal is facing towards the fan housing. Align marking "A", located at the bottom of the fan housing, with marking "A" on the top end of the pedestal. Insert the alignment post from the pedestal into the alignment hole on fan housing for proper alignment. Use 4 screws (M4x8mm) provided to attach the assembled base to the pedestal. Secure the screws with a screwdriver. Wind the power cord underneath the base. Loosen the cord clip and place cord inside the clip. Secure the cord clip onto the base bottom with the 2 screws (M4x12mm) provided. Turn fan right side up and place on a dry and level surface before operating. OPERATING INSTRUCTIONS Power/Speed Settings / Press / = On, I, II, III, Off Timer Control Press = Turns Off in 1, 2, 4, 8 hours Oscillation Control Press = Oscillation On, Off Natural Breeze, Sleep Breeze Modes / Press / = Natural Breeze, Sleep Breeze Natural Breeze Mode will cycle through the fan speed settings randomly. Sleep Breeze Mode will cycle through the fan speed settings in order. FCC STATEMENT Potential for Radio/Television Interference This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: This device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation. This product has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. REMOTE CONTROL This fan includes a remote control requiring two (2) AAA batteries, 1.5V (not included). Battery Replacement Remove battery cover from remote control. Remove old batteries from the remote control. Insert two new batteries, pressing them firmly into their slot. Replace the battery cover. NOTES: Replace all batteries of a set at the same time. Being careful not to bend or damage the contact spring, clean the battery contacts and devices' contacts prior to installing the batteries. Remove the batteries from the equipment when it is not being used for an extended period of time. Remove the used batteries promptly. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries. Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area. CLEANING/MAINTENANCE INSTRUCTIONS Follow these instructions to correctly and safely care for your Tower Fan. Please remember: REPLACEABLE FUSE If your (5 Amp, 125 Volt) replaceable fuse blows, please visit our website at www.holmesproducts.com for information on how to order a new fuse. Follow the below instructions to replace the fuse on the plug. User Servicing Instructions Unplug your fan. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord. Open fuse cover, located on the top of the plug, by using your thumb or a flathead screwdriver to slide the cover down towards the prongs. Note: Ensure that fuse cover is completely open before attempting to remove fuse. Remove fuse carefully by using a small screwdriver to pry the fuse out of the compartment by the metal ends of the fuse. Place plug on a solid, flat surface. Insert new 5 Amp, 125 Volt fuse into fuse compartment and use a small screwdriver to secure the metal ends of the fuse into the compartment. Risk of fire. Replace fuse only with 5 Amp, 125 Volt fuse. Slide fuse cover closed completely. If fuse cover is difficult to close, make sure fuse is secured in place completely by pressing down on metal ends of the fuse. Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if the attachment plug is damaged. Fan CLEANING Always unplug the fan before cleaning. Clean fan housing 2 pedestal halves 2 base halves 8 M4x8mm screws (4 pcs for pedestal assembly and 4 pcs for base assembly) Cord clip with 2 M4x12mm screws (affixed underneath the base inside the package box) Remote Control (placed in a plastic bag inside the package box) Follow the steps below in order to assemble the fan pedestal and base before operating your fan: To assemble the pedestal, simply snap the 2 pedestal halves together. Pull the power cord through the assembled pedestal, making sure the wider end of the pedestal is facing towards the fan housing. Align marking "A", located at the bottom of the fan housing, with marking "A" on the top end of the pedestal. Insert the alignment post from the pedestal into the alignment hole on fan housing for proper alignment. Use 4 screws (M4x8mm) provided to attach the assembled base to the pedestal. Secure the screws with a screwdriver. Wind the power cord underneath the base. Loosen the cord clip and place cord inside the clip. Secure the cord clip onto the base bottom with the 2 screws (M4x12mm) provided. Turn fan right side up and place on a dry and level surface before operating. OPERATING INSTRUCTIONS Power/Speed Settings / Press / = On, I, II, III, Off Timer Control Press = Turns Off in 1, 2, 4, 8 hours Oscillation Control Press = Oscillation On, Off Natural Breeze, Sleep Breeze Modes / Press / = Natural Breeze, Sleep Breeze Natural Breeze Mode will cycle through the fan speed settings randomly. Sleep Breeze Mode will cycle through the fan speed settings in order. FCC STATEMENT Potential for Radio/Television Interference This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: This device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation. This product has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. REMOTE CONTROL This fan includes a remote control requiring two (2) AAA batteries, 1.5V (not included). Battery Replacement Remove battery cover from remote control. Remove old batteries from the remote control. Insert two new batteries, pressing them firmly into their slot. Replace the battery cover. NOTES: Replace all batteries of a set at the same time. Being careful not to bend or damage the contact spring, clean the battery contacts and devices' contacts prior to installing the batteries. Remove the batteries from the equipment when it is not being used for an extended period of time. Remove the used batteries promptly. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries. Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area. CLEANING/MAINTENANCE INSTRUCTIONS Follow these instructions to correctly and safely care for your Tower Fan. Please remember: REPLACEABLE FUSE If your (5 Amp, 125 Volt) replaceable fuse blows, please visit our website at www.holmesproducts.com for information on how to order a new fuse. Follow the below instructions to replace the fuse on the plug. User Servicing Instructions Unplug your fan. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord. Open fuse cover, located on the top of the plug, by using your thumb or a flathead screwdriver to slide the cover down towards the prongs. Note: Ensure that fuse cover is completely open before attempting to remove fuse. Remove fuse carefully by using a small screwdriver to pry the fuse out of the compartment by the metal ends of the fuse. Place plug on a solid, flat surface. Insert new 5 Amp, 125 Volt fuse into fuse compartment and use a small screwdriver to secure the metal ends of the fuse into the compartment. Risk of fire. Replace fuse only with 5 Amp, 125 Volt fuse. Slide fuse cover closed completely. If fuse cover is difficult to close, make sure fuse is secured in place completely by pressing down on metal ends of the fuse. Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if the attachment plug is damaged. Fan CLEANING Always unplug the fan before cleaning. Clean fan housing 2 pedestal halves 2 base halves 8 M4x8mm screws (4 pcs for pedestal assembly and 4 pcs for base assembly) Cord clip with 2 M4x12mm screws (affixed underneath the base inside the package box) Remote Control (placed in a plastic bag inside the package box) Follow the steps below in order to assemble the fan pedestal and base before operating your fan: To assemble the pedestal, simply snap the 2 pedestal halves together. Pull the power cord through the assembled pedestal, making sure the wider end of the pedestal is facing towards the fan housing. Align marking "A", located at the bottom of the fan housing, with marking "A" on the top end of the pedestal. Insert the alignment post from the pedestal into the alignment hole on fan housing for proper alignment. Use 4 screws (M4x8mm) provided to attach the assembled base to the pedestal. Secure the screws with a screwdriver. Wind the power cord underneath the base. Loosen the cord clip and place cord inside the clip. Secure the cord clip onto the base bottom with the 2 screws (M4x12mm) provided. Turn fan right side up and place on a dry and level surface before operating. OPERATING INSTRUCTIONS Power/Speed Settings / Press / = On, I, II, III, Off Timer Control Press = Turns Off in 1, 2, 4, 8 hours Oscillation Control Press = Oscillation On, Off Natural Breeze, Sleep Breeze Modes / Press / = Natural Breeze, Sleep Breeze Natural Breeze Mode will cycle through the fan speed settings randomly. Sleep Breeze Mode will cycle through the fan speed settings in order. FCC STATEMENT Potential for Radio/Television Interference This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: This device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation. This product has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. REMOTE CONTROL This fan includes a remote control requiring two (2) AAA batteries, 1.5V (not included). Battery Replacement Remove battery cover from remote control. Remove old batteries from the remote control. Insert two new batteries, pressing them firmly into their slot. Replace the battery cover. NOTES: Replace all batteries of a set at the same time. Being careful not to bend or damage the contact spring, clean the battery contacts and devices' contacts prior to installing the batteries. Remove the batteries from the equipment when it is not being used for an extended period of time. Remove the used batteries promptly. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries. Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area. CLEANING/MAINTENANCE INSTRUCTIONS Follow these instructions to correctly and safely care for your Tower Fan. Please remember: REPLACEABLE FUSE If your (5 Amp, 125 Volt) replaceable fuse blows, please visit our website at www.holmesproducts.com for information on how to order a new fuse. Follow the below instructions to replace the fuse on the plug. User Servicing Instructions Unplug your fan. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord. Open fuse cover, located on the top of the plug, by using your thumb or a flathead screwdriver to slide the cover down towards the prongs. Note: Ensure that fuse cover is completely open before attempting to remove fuse. Remove fuse carefully by using a small screwdriver to pry the fuse out of the compartment by the metal ends of the fuse. Place plug on a solid, flat surface. Insert new 5 Amp, 125 Volt fuse into fuse compartment and use a small screwdriver to secure the metal ends of the fuse into the compartment. Risk of fire. Replace fuse only with 5 Amp, 125 Volt fuse. Slide fuse cover closed completely. If fuse cover is difficult to close, make sure fuse is secured in place completely by pressing down on metal ends of the fuse. Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if the attachment plug is damaged. Fan CLEANING Always unplug the fan before cleaning. Clean fan housing 2 pedestal halves 2 base halves 8 M4x8mm screws (4 pcs for pedestal assembly and 4 pcs for base assembly) Cord clip with 2 M4x12mm screws (affixed underneath the base inside the package box) Remote Control (placed in a plastic bag inside the package box) Follow the steps below in order to assemble the fan pedestal and base before operating your fan: To assemble the pedestal, simply snap the 2 pedestal halves together. Pull the power cord through the assembled pedestal, making sure the wider end of the pedestal is facing towards the fan housing. Align marking "A", located at the bottom of the fan housing, with marking "A" on the top end of the pedestal. Insert the alignment post from the pedestal into the alignment hole on fan housing for proper alignment. Use 4 screws (M4x8mm) provided to attach the assembled base to the pedestal. Secure the screws with a screwdriver. Wind the power cord underneath the base. Loosen the cord clip and place cord inside the clip. Secure the cord clip onto the base bottom with the 2 screws (M4x12mm) provided. Turn fan right side up and place on a dry and level surface before operating. OPERATING INSTRUCTIONS Power/Speed Settings / Press / = On, I, II, III, Off Timer Control Press = Turns Off in 1, 2, 4, 8 hours Oscillation Control Press = Oscillation On, Off Natural Breeze, Sleep Breeze Modes / Press / = Natural Breeze, Sleep Breeze Natural Breeze Mode will cycle through the fan speed settings randomly. Sleep Breeze Mode will cycle through the fan speed settings in order. FCC STATEMENT Potential for Radio/Television Interference This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: This device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation. This product has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. REMOTE CONTROL This fan includes a remote control requiring two (2) AAA batteries, 1.5V (not included). Battery Replacement Remove battery cover from remote control. Remove old batteries from the remote control. Insert two new batteries, pressing them firmly into their slot. Replace the battery cover. NOTES: Replace all batteries of a set at the same time. Being careful not to bend or damage the contact spring, clean the battery contacts and devices' contacts prior to installing the batteries. Remove the batteries from the equipment when it is not being used for an extended period of time. Remove the used batteries promptly. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries. Do not discard used batteries into household trash containers. Contact your local government for disposal or recycling practices in your area. CLEANING/MAINTENANCE INSTRUCTIONS Follow these instructions to correctly and safely care for your Tower Fan. Please remember: REPLACEABLE FUSE If your (5 Amp, 125 Volt) replaceable fuse blows, please visit our website at www.holmesproducts.com for information on how to order a new fuse. Follow the below instructions to replace the fuse on the plug. User Servicing Instructions Unplug your fan. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord. Open fuse cover, located on the top of the plug, by using your thumb or a flathead screwdriver to slide the cover down towards the prongs. Note: Ensure that fuse cover is completely open before attempting to remove fuse. Remove fuse carefully by using a small screwdriver to pry the fuse out of the compartment by the metal ends of the fuse. Place plug on a solid, flat surface. Insert new 5 Amp, 125 Volt fuse into fuse compartment and use a small screwdriver to secure the metal ends of the fuse into the compartment. Risk of fire. Replace fuse only with 5 Amp, 125 Volt fuse. Slide fuse cover closed completely. If fuse cover is difficult to close, make sure fuse is secured in place completely by pressing down on metal ends of the fuse. Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if the attachment plug is damaged. Fan CLEANING Always unplug the fan before cleaning. Clean fan housing 2 pedestal halves 2 base halves 8 M4x8mm screws (4 pcs for pedestal assembly and 4 pcs for base assembly) Cord clip with 2 M4x12mm screws (affixed underneath the base inside the package box) Remote Control (placed in a plastic bag inside the package box) Follow the steps below in order to assemble the fan pedestal and base before operating your fan: To assemble the pedestal, simply snap the 2 pedestal halves together. Pull the power cord through the assembled pedestal, making sure the wider end of the pedestal is facing towards the fan housing. Align marking "A", located at the bottom of the fan housing, with marking "A" on the top end of the pedestal. Insert the alignment post from the pedestal into the alignment hole on fan housing for proper alignment. Use 4 screws (M4x8mm) provided to attach the assembled base to the pedestal. Secure the screws with a screwdriver. Wind the power cord underneath the base. Loosen the cord clip and place cord inside the clip. Secure the cord clip onto the base bottom with the 2 screws (M4x12mm) provided. Turn fan right side up and place on a dry and level surface before operating. OPERATING INSTRUCTIONS Power/Speed Settings / Press / = On, I, II, III, Off Timer Control Press = Turns Off in 1, 2, 4, 8 hours Oscillation Control Press = Oscillation On, Off Natural Breeze, Sleep Breeze Modes / Press / = Natural Breeze, Sleep